

SOLA-Messwerkzeuge GmbH

Unteres Tobel 25, A-6840 Götztis





Tel: +43 (0)5523 53380-0, Fax: +43 (0)5523 53385

sola@sola.at, www.sola.at




Please find the operating instructions at  
[www.sola.at](http://www.sola.at)

R373262



## QUICK START VECTOR 80



- 1 ON/Measure button
- 2 Function button
- 3 Min/Max and continuous measurement
- 4 Add/subtract
- 5 Memory
- 6 Measurement edge
- 7 Backlighting/unit of measurement
- 8 OFF/Delete button

MEAS ON CLEAR OFF Unit

MEAS ON 2 sec. → ON

CLEAR OFF 2 sec. → OFF

1

MEAS ON 1x

3

MAX/MIN 1x MEAS ON 1x = STOP

5

2x

7

1x

2

MAX/MIN 1x MEAS ON 1x = STOP

4

1x

6

3x

8